

SPARE PARTS LIST

MODEL NO. BJV180

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	188207-9	HANDLE SET /BJV180Z INC. 25	1	
002	266048-4	TAPPING SCREW 4 X 40 /4341T/4334DWA	1	
003	266091-3	TAPPING SCREW 4 X 50 /4340T/4351FCT	1	
004	265995-6	TAPPING SCREW4x18/HR2440F/HR2450F/BSS610	5	
005	442138-9	PACKING /4340T/4351FCT	1	
006	214031-5	PLANE BEARING 4 /6913DWA/4340T/4351FCT	1	
007	232207-2	LEAF SPRING /4340T /4351FCT	1	
008	256117-9	PIN 4 /JR3010/4340T/4329/4351FCT	1	
009	911111-5	P.H.SCREW M4 X 10 /5057KB/BO3700/9924DB	2	
010	911111-5	P.H.SCREW M4 X 10 /5057KB/BO3700/9924DB	2	
011	345240-6	LINEAR GUIDE /4340T/4351FCT	1	
012	345240-6	LINEAR GUIDE /4340T/4351FCT	1	
013	153338-3	GEAR HOUSING COVER COMPLETE /4340T/	1	
014	631744-7	LIGHT CIRCUIT /BJV180Z	1	
015	689070-8	RADIATING PLATE /6914DWBE/BTW200SJE/	1	
016	911006-2	P.H. SCREW M3 X 8 /BHR200SFE/BHR200SJE	1	
017	232152-1	LEAF SPRING /6832	1	
018	419613-0	LOCK OFF BUTTON /BJV180Z	1	
019	650584-4	SWITCH /BJV180Z	1	
020	233118-4	COMPRESSION SPRING 4 /AF502	1	
021	419754-2	SWITCH LEVER /BJV180Z	1	
022	324233-6	SAFETY WIRE /4340T/4351FCT	1	
023	266034-5	TAPPING SCREW CT 4 X 16 /HK0500/LS1013B/	4	
024	643812-4	TERMINAL/ BHP451/BSS610/BCS550/BGA452RFE	1	
025	188207-9	HANDLE SET /BJV180Z INC. 1	1	
026	268090-1	PIN 4 /4340T/4340CT/4351FCT	1	
027	961017-7	STOP RING /HR2450/HR2450F/4304T/4340T	1	
028	310134-4	SLIDER /4340T/4351FCT	1	
029	231659-4	TORSION SPRING 6 /4340T/4340CT/4351FCT	1	
030	419820-5	TOOL OPENER /BJV180Z /4351FCT	1	
031	265026-1	+ P.H. SCREW M4 /3901/4340T/4351FCT	1	
032	310135-2	PUSH PIN /4340T/4351FCT	1	
033	421817-2	DUST COVER /4340T/4351FCT	1	
034	962068-3	RETAINING RING R-18 /4340T/4351FCT	1	
035	165326-8	ROD /4340T/4351FCT	1	
036	231660-9	TORSION SPRING 15 /4340T/4351FCT	1	
037	310136-0	BLADE HOLDER /4340T/4351FCT	1	
038	188208-7	MOTOR HOUSING SET /BJV180Z INC. 63	1	
039	265995-6	TAPPING SCREW4x18/HR2440F/HR2450F/BSS610	4	
040	862966-0	BJV180 NAME PLATE	1	
041	638504-8	ENDBELL COMPLETE /BJV180Z	1	
042	638373-7	YOKE UNIT /BJV180Z	1	
043	619206-5	ARMATURE /BJV180Z	1	
044	961004-6	RETAINING RING S-8 /4351FCT	1	
045	212014-9	NEEDLE BEARING 407 /4340T/4351FCT	1	
046	265353-6	HEX.SOCKET HEAD BOLT M4 X 12 /4340T/	2	
047	153336-7	CRANK COMPLETE /4340T/4351FCT	1	
048	313108-4	BALANCE PLATE /4340T/4351FCT	1	
049	158168-7	GEAR COMPLETE /BJV180Z	1	
050	345235-9	PUSH PLATE /4340T/4351FCT	1	
051	253877-4	FLAT WASHER 8 /4301BV/4340T/4351FCT	1	
052	266050-7	TAPPING SCREW 4 X 30 /JS8000	4	
053	961018-5	STOP RING E-5 /4304T/LS800DWA/4331DWA	1	

SPARE PARTS LIST

MODEL NO. BJV180

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
054	417839-8	SEAL PLATE /4340T/4340CT/4351FCT	1	
055	286032-3	CAP 5 /4341CT/4351FCT	1	
056	233139-6	COMPRESSION SPRING 3	1	
057	272244-4	LEVER 17 /4340T/4351FCT	1	
058	268063-4	PIN 4 /4340T/4351FCT	1	
059	158169-5	GEAR HOUSING COMPLETE	1	
060	252171-1	SQUARE NUT M5-8 /4340T/4351FCT	1	
061	421816-4	DUST SEAL /4340T/4351FCT	1	
062	153334-1	RETAINER COMPLETE /4340T/4351FCT	1	
063	188208-7	MOTOR HOUSING SET /BJV180Z	1	
		INC. 38		
064	191971-3	CARBON BRUSH CB-430	1	
065	643807-7	BRUSH HOLDER CAP	2	
066	232208-0	LEAF SPRING /4340T/4351FCT	1	
067	922226-3	H.S.H. M5 X 18 /4340T/4351FCT	1	
068	345237-5	CRANK PLATE /4340T/4351FCT	1	
069	317565-8	BASE /4340T/4351FCT	1	
070	912107-9	C.S.H. SCREW M4 X 8 /5620DWA/5621DWFE	4	
071	345238-3	BASE PLATE /4340T/4351FCT	1	
A01	415524-7	ANTI-SPLINTERING DEVICE /4304T/4331DWA	1	
A02	417852-6	COVER PLATE /4340T/4340CT/4340FCT/4341T	1	
A03	*****	*****	***	*****
A04	*****	*****	***	*****
A05	*****	*****	***	*****
A06	783202-0	HEX.WRENCH 4MM /1050DWA/AN503/AN513	1	
A07	*****	*****	***	*****
A08	*****	*****	***	*****
A09	*****	*****	***	*****
A10	804931-3	BJV180RF TOOL LABEL	1	

SERVICE DRAWING

MODEL NO. BJV180

