

# SPARE PARTS LIST

MODEL NO. BTL061

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	188397-8	HOUSING SET INC. 40	1	
002	265995-6	TAPPING SCREW 4X18	8	
003	864078-5	BTL061 NAME PLATE	1	
004	643843-3	TERMINAL	1	
005	263036-2	RUBBER PIN 5	1	
006	268184-2	PIN 1.5	1	
007	424026-2	CUSHION	1	
008	450126-2	FR CHANGE LEVER	1	
009	450125-4	SWITCH LEVER	1	
010	631778-0	LED CIRCUIT	1	
011	650594-1	SWITCH C3HY-1A-PLM	1	
012	265409-5	+ HEX. BOLT M5X30	1	
013	152461-1	ANGLE HEAD COMPLETE	1	
014	226720-0	ZEROL BEVEL GEAR 13	1	
015	211064-1	BALL BEARING 6000	1	
016	257660-1	SLEEVE 10	1	
017	211061-7	BALL BEARING 6000LLB	1	
018	961006-2	RETAINING RING S-10	1	
019	962105-3	RETAINING RING R-26	1	
020	257662-7	SLEEVE 15	1	
021	261095-0	RUBBER WASHER 21	1	
022	267120-5	FLAT WASHER 15	1	
023	322689-7	ANVIL	1	
024	322688-9	HAMMER	1	
025	216001-0	STEEL BALL 3.5	22	
026	267121-3	FLAT WASHER 20	1	
027	233107-9	COMPRESSION SPRING 22	1	
028	629846-1	DC MOTOR	1	
029	267053-4	FLAT WASHER 12	1	
030	226280-2	INTERNAL GEAR 69	1	
031	257187-1	RING 32	1	
032	226279-7	SPUR GEAR 29	1	
033	226279-7	SPUR GEAR 29	1	
034	154416-2	SPINDLE COMPLETE	1	
035	216002-8	STEEL BALL 4.8	1	
036	211064-1	BALL BEARING 6000	1	
037	322719-4	WASHER 10	1	
038	226279-7	SPUR GEAR 29	1	
039	216002-8	STEEL BALL 4.8	1	
040	188397-8	HOUSING SET INC. 1	1	
041	216001-0	STEEL BALL 3.5	1	
042	424044-0	RUBBER RING 32	1	
043	231990-8	RING SPRING 9	1	
044	226721-8	ZEROL BEVEL GEAR 13	1	
045	211131-2	BALL BEARING 6001DDW	1	
046	323922-0	SPINDLE N	1	
047	216001-0	STEEL BALL 3.5	1	
048	322718-6	SLEEVE	1	
049	233005-7	COMPRESSION SPRING 13	1	
050	267085-1	FLAT WASHER 12	1	
051	231951-8	RING SPRING 11	1	
052	962116-8	RETAINING RING R-28	1	
053	324705-1	HOOK	1	
054	251314-2	+ SCREW M4X12	1	

# SPARE PARTS LIST

---

MODEL NO. BTL061

---

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
055	135183-8	ANGLE HEAD ASS'Y INC. 12-19,41-52	1	

---

# SERVICE DRAWING

MODEL NO. BTL061

