

SPARE PARTS LIST

MODEL NO. DHP459

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	187454-9	4mAg1a [1] OBUDOWA KPL. P+L do BHP459 INC. 21	1	
002	897431-0	BHP459 NAME PLATE	1	
003	266429-2	4bAj1a [1] SRUBA 3x16	9	
004	419250-0	4bVj4a [1] PRZELACZNIK ZMIANY KIERUNKU OBROTÓW do BDF/BHP441-451		
005	650689-0	6aDf2k [1] WLACZNIK do BTD129/BHP/BDF459	1	
006	619304-5	6iYd1i [1] WIRNIK do BHP459/BDF459	1	
007	629960-3	4qSe1b [1] STOJAN do BDF/BHP459	1	
008	620163-2	4bRh3c [1] OBWÓD LED do GA7020R	1	
009	643860-3	6aGa3m [1] zam.643888-1(TI.92166)TERMINAL do BCL182	1	
010	126180-5	4bRh5c [1] PRZELACZNIK ZMIANY PREDKOSCI KPL. do BHP459/BDF459/BTD129		
011	232182-2	4bEi8e [1] SPREZYNA PLASKA	1	
012	251468-5	4bFj9d [1] SRUBA M6x22	1	
013	763175-3	4jYn1b [3] (zam. 196311-0) SAMOZACISKOWY UCHWT WIERTARSKI 13mm do BDF430		
014	126179-0	4sOf1a [1] PRZEKLADNIA do BHP459/BDF459/BTD129	1	
015	266786-8	4aBi5d [1] SRUBA PT2x10 do BHP459/BDF459/BTD129	4	
016	620162-4	6aEe5a [1] KONTROLER do DF459D	1	
017	687464-1	4aBi8e [1] WSPORNIK do BHP459/BDF459/BTD129	1	
018	424517-3	4aCg8d [1] PODKLADKA AMORTYZUJACA do BHP459/BDF459/BTD129		
021	187454-9	4mAg1a [1] OBUDOWA KPL. P+L do BHP459 INC. 1	1	
A01	251314-2	4bFj2a [1] SRUBA 4X12	1	
A02	346317-0	4cAc1b [3] HACZYK do BDF/BHP456	1	
A03	784637-8	4jZn1b [3] (+ -) BIT NR 2-45MM 1/4"	1	
A04	***DC18RC	DC18RC FAST CHARGER	1	
A05	194204-5	6iRc1c [3] AKUMULATOR BL1830 Li-Ion 18V 3.0Ah	2	
A06	450128-8	4bXc3b [3] OSŁONA STYKÓW AKUMULATORA	1	
A07	*****	*****	***	*****
A08	*****	*****	***	*****
A09	*****	*****	***	*****
A10	*****	*****	***	*****

SERVICE DRAWING

MODEL NO. DHP459

