

# SPARE PARTS LIST

MODEL NO. BTW250

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	*****	*****	***	*****
002	862816-9	BTW250 NAME PLATE	1	
003	266130-9	TAPPING SCREW BIND PT 3x16/6932FDWPE/	8	
004	643811-6	TERMINAL/BHR162Z/BTW250/BTW251/BHP444RFE	1	
005	419041-9	F/R CHANGE LEVER /BTW250/BTW251	1	
006	650564-0	SWITCH TG553FSB-1	1	
007	652045-0	PAN HEAD SCREW M3.5x5 / BTD130FRFE	2	
008	*****	*****	***	*****
009	*****	*****	***	*****
010	*****	*****	***	*****
011	261116-8	NYLON WASHER 18 /6934/BTW250/BTW251	1	
012	231907-1	RING SPRING 10 /6931DW/BTW200SJE/BTW250	1	
015	324706-9	ANVIL/BTW251/BTW250	1	
016	324703-5	HAMMER/BTW251/BTW250	1	
017	216001-0	STEEL BALL 3.5 /HP2040/HP2041/MT811K	24	
018	267175-0	FLAT WASHER 24 /6914DWFE/BHR162Z/BTW250	1	
019	*****	*****	***	*****
020	267766-7	CUP WASHER 14 /6934FDWAE/BTW250/BTW251	1	
021	216011-7	STEEL BALL 5.6 /BTW250/BTW251	2	
022	*****	*****	***	*****
023	324220-5	SPINDLE /6934FDWAE /BTW250/BTW251	1	
024	256253-1	PIN 5 /6914DWBE /BTW250/BTW251	2	
025	267212-0	FLAT WASHER 12 /BO4901/HR2230X/BTW250	1	
026	227150-8	INTERNAL GEAR 51/BTD140RFE/BTW250/BTW251	1	
027	213507-9	O RING 40	1	
028	158145-9	BEARING BOX COMPLETE/BTW251/BTW250	1	
029	638495-3	YOKE UNIT/BTW251/BTW250	1	
030	*****	*****	***	*****
031	*****	*****	***	*****
032	638498-7	BRUSH HOLDER COMPLETE/BTW251/BTW250	1	
033	263032-0	RUBBER PIN 4 / BTS130/BHP441/BHP452	2	
034	418981-8	REAR COVER	1	
035	266130-9	TAPPING SCREW BIND PT 3x16/6932FDWPE/	2	
036	631631-0	LIGHT CIRCUIT	1	
038	*****	*****	***	*****
039	324705-1	HOOK/BTW251/BHP452/BTW250/BHP442Z/BTL061	1	
040	251314-2	SCREW M4 X 12 /LS0800/BDF441/BHP442Z	1	
041	424026-2	CUSHION/BTW251/BHP452/BTW250/BHP442Z	1	
042	263036-2	RUBBER PIN 5/BTW251/BTW250/BTL061Z	1	
043	268184-2	PIN 1.5/BTW251/BTW250/BTL061Z	1	
A01	***DC18RA	DC18RA FAST CHARGER	1	
A02	*****	*****	***	*****
A03	*****	*****	***	*****
A04	804678-9	BTW250RFE PLASTIC CASE LABEL	1	
A05	450128-8	LXT BATTERY COVER/BHR202RFE/BHP444RFE/	1	

# SERVICE DRAWING

MODEL NO. BTW250

