

SPARE PARTS LIST

MODEL NO. BHR202

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	286263-4	CAP 35 /HR2440/HR2450/HR2440F/HR2450F	1	
002	233940-9	RING SPRING/BHR202RFE/HR2450/HR2450FT	1	
003	417629-9	CHUCK COVER/HR2440/HR2450/HR2440F/HR2020	1	
004	257241-1	RING 21 /HR2440/HR2450/HR2440F/HR2450F	1	
005	345187-4	GUIDE WASHER /HR2440/HR2450/HR2440F	1	
006	233916-6	CONICAL COMP.SPRING 21-29 /HR2440/HR2450	1	
007	921923-8	HEX.BOLT M8 X 120 /HR2440/HR2450/HR2440F	1	
008	345280-4	HEX.WASHER /HR2440/HR2450/HR2440F/HR2020	1	
009	417630-4	GRIP BASE /HR2440/HR2450/HR2440F/HR2450F	1	
010	158057-6	GRIP 36 COMPLETE /HR2470/HR2470FT/	1	
013	162245-9	CHANGE LEVER /HR2470/HR2470FT/BHR202RFE	1	
014	233459-8	COMPRESSION SPRING 3 / HR1830/BHR162Z	1	
015	419192-8	LOCK BUTTON / HR1830/BHR162Z/HR2230X	1	
016	213278-8	O RING 17 /HR2440/HR2450/HR2440F/HR2450F	1	
017	158216-2	GEAR HOUSING COMPLETE /HR2470/HR2470FT	1	
018	266351-3	(+) PAN HEAD SCREW M4X35 /MT370/HR2230X/	4	
019	153290-5	NEEDLE BEARING COMPLETE /HR2440/HR2450/	1	
020	961017-7	STOP RING /HR2450/HR2450F/4304T/4340T	2	
021	417796-0	GUIDE BASE /HR2450/HR2450F/BHR240RFE/	1	
022	233344-5	COMPRESSION SPRING 4 /HR2450/HR2450F	2	
023	163430-7	LOCK PLATE COMPLETE /HR2450/HR2450F	1	
024	266374-1	TAPPING SCREW 4X25/ GA9020/HR2470FT/	2	
025	233929-7	RING SPRING 29 /HR2450FT/HR240RFE/	1	
026	267791-8	WASHER 31 /HR2470/HR2470FT/BHR240RFE/	1	
027	233401-9	COMPRESSION SPRING 32/HR2450FT/BHR202RFE	1	
028	227109-5	SPUR GEAR 51/HR2450FT/BHR240RFE	1	
029	216022-2	STEEL BALL 7/HR2440/HR2450/HR2400/HR2230	1	
030	158574-6	TOOL HOLDER COMPLETE /HR2470/BHR202RFE	1	
031	267229-3	FLAT WASHER 28 /HR2440/HR2450/HR2440F	1	
032	331769-8	SLEEVE 9 /HR2470/HR2470FT/HR2230X/	1	
033	324669-9	IMPACT BOLT /HR2470/HR2230X/BHR240RFE	1	
034	324402-9	RING 10 /HR2450FT/HR2230X/BHR240RFE	1	
035	421955-0	CUSHION RING /HR2470/HR2470FT/HR2230X	1	
036	324216-6	RING CASE /HR2440/HR2450/HR2440F	1	
037	213073-6	O RING 9 /HR2440/HR2450/HR2440F/HR2450F	1	
038	233917-4	RING SPRING 28 /HR2440/HR2450/HR2440F	1	
039	324214-0	STRIKER /HR2440/HR2450/HR2440F/HR2450F	1	
040	213227-5	O RING 16 /HK0500/HR2440/HR2450/HR2440F	1	
041	318132-2	PISTON CYLINDER /HR2470/HR2470FT/	1	
042	267104-3	FLAT WASHER 12 /HR2440/HR2450/HR2440F	1	
043	324215-8	PISTON JOINT /HR2440/HR2450/HR2440F	1	
044	267104-3	FLAT WASHER 12 /HR2440/HR2450/HR2440F	1	
045	213727-5	O-RING 63 /HR2470/HR2470FT/HR2230X/	1	
046	211012-0	BALL BEARING 606ZZ/BHR162Z/HR2450/HR2020	1	
047	961003-8	RETAINING RING S-7 /HR2450/HR2450F/	1	
048	233343-7	COMPRESSION SPRING 7 /HR2450/HR2450F/	1	
049	227179-4	SPUR GEAR 10/HR2470/HR2470FT/BHR202RFE/	1	
050	324668-1	CAM SHAFT /HR2470/HR2470FT/BHR240RFE/	1	
051	331768-0	CLUTCH CAM /HR2470/HR2470FT/BHR202RFE	1	
052	219014-0	SWASH BEARING 10 /HR2440/HR2450/HR2440F	1	
053	226632-7	HELICAL GEAR 25 /BHR240RFE/BHR202RFE/	1	
054	266273-7	HSH BOLT M4 X 12 /4604DW/HR2440/HR2450	2	
055	345179-3	BEARING RETAINER /HR2450/HR2440F/HR2450F	1	
056	267234-0	FLAT WASHER 8 /HR2440/HR2450/HR2440F	1	
057	211032-4	BALL BEARING 608ZZ /HR2440/HR2450/6411	1	
058	324212-4	RING 8 /HR2440/HR2450/HR2440F/HR2450F	1	

SPARE PARTS LIST

MODEL NO. BHR202

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
059	961011-9	STOP RING E-4 /HR2450/HR2450F/4329	1	
060	941102-2	FLAT WASHER 5 /AF502/HR2450F/BHR240RFE/	1	
061	233342-9	COMPRESSION SPRING 6 /HR2450/HR2450F/	1	
062	345363-0	CHANGE PLATE /HR2450/HR2450F/BHR240RFE/	1	
063	158215-4	INNER HOUSING COMPLETE /HR2470/HR2470FT	1	
064	443126-9	FELT /HR2470/HR2470FT/HR2230X/BHR240RFE/	1	
065	213407-3	O RING 26 /5600NB/4101RH/HR2230X/HR4511C	1	
066	213077-8	OIL SEAL 10 /HR2470/HR2470FT/HR2230X/	1	
067	210059-1	BALL BEARING /HR4000C/HR5201C/HR2230X	1	
068	267213-8	FLAT WASHER 10 /HR2470/HR2470FT/HR2230X/	1	
069	240092-9	FAN 64/HR2470/HR2470FT/HR2230X/	1	
070	519226-8	ARMATURE ASSY 18 VOLT /BHR202RFE INC. 67-69,71,72	1	
071	253823-7	FLAT WASHER 7	1	
072	210023-2	BALL BEARING 627DDW /9910/5621DWFE/9032	1	
073	267816-8	WAVE WASHER 15 /BHR202RFE	1	
074	865285-3	BHR202 NAME PLATE	1	
075	188515-8	HOUSING SET INC 82 /BHR202RFE INC. 82	1	
076	638020-0	YOKE UNIT /BTW200SJE/BHR202RFE/	1	
077	643834-4	BRUSH HOLDER /BHR202RFE	1	
078	643835-2	BRUSH HOLDER /BHR202RFE	1	
079	266326-2	TAPPING SCREW 4X18 /MT240/9556PB/HR4002	2	
080	911006-2	P.H. SCREW M3 X 8 /BHR200SFE/BHR200SJE	1	
081	689070-8	RADIATING PLATE /6914DWBE/BTW200SJE/	1	
082	188515-8	HOUSING SET INC 82 /BHR202RFE INC. 75	1	
083	424128-4	HOLDER CAP COVE /BHR202RFE	2	
084	643829-7	HOLDER CAP /BHR202RFE	2	
085	194435-6	CARBON BRUSH CB-441/JR180D/LS711D/5026D	1	
086	424111-1	SWITCH COVER /BHR202RFE	1	
087	450615-7	F/R CHANGE LEVER /BHR202RFE	1	
088	650578-9	SWITCH TG553FSB-6/BHR162Z/BHR202RFE/	1	
089	631792-6	LIGHT CIRCUIT /BHR202RFE	1	
090	266326-2	TAPPING SCREW 4X18 /MT240/9556PB/HR4002	7	
091	*****	*****	***	*****
092	188453-4	BATTERY HOUSING SET /BHR202RFE INC. 95	1	
093	263036-2	RUBBER PIN 5/BTW251/BTW250/BTL061Z	1	
094	268184-2	PIN 1.5/BTW251/BTW250/BTL061Z	1	
095	188453-4	BATTERY HOUSING SET /BHR202RFE INC. 92	1	
096	266326-2	TAPPING SCREW 4X18 /MT240/9556PB/HR4002	2	
097	424042-4	CUSHION RUBBER /BHR202RFE	1	
098	424026-2	CUSHION/BTW251/BHP452/BTW250/BHP442Z	1	
099	424042-4	CUSHION RUBBER /BHR202RFE	1	
100	122881-3	TOOL HOLDER ASSEMBLY INC. 25-28,30,32-38	1	
A01	324219-0	DEPTH GAUGE /HR2440/HR2450/HR2440F	1	
A02	194204-5	BATTERY BL1830 /BHP452/BHR202RFE/	2	
A03	450128-8	LXT BATTERY COVER/BHR202RFE/BHP444RFE/	1	
A04	***DC18RA	DC18RA FAST CHARGER	1	
A05	824861-2	PLASTIC CARRYING CASE	1	

SERVICE DRAWING

MODEL NO. BHR202

