

SPARE PARTS LIST

MODEL NO. BJR181

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	*****	*****	***	*****
002	421945-3	INSULATION COVER /BJR181RF	1	
003	*****	*****	***	*****
004	*****	*****	***	*****
005	*****	*****	***	*****
006	256492-3	SHOULDER PIN 5 / JR3070CT	1	
007	233345-3	COMPRESSION SPRING /BJR240SJE	1	
008	268094-3	PIN 3 /BJR240SJE	1	
009	*****	*****	***	*****
010	256158-5	PIN 3 /T422D/6835DWAE/LS800DWA/3707F	1	
011	417791-0	DRIVING SLEEVE GUIDE /BJR240SJE	1	
012	418311-3	SLEEVE /JR3050T	1	
013	345214-7	PUSH PLATE /BJR240SJE	1	
014	233025-1	COMPRESSION SPRING 2 /BJR240SJE	1	
015	231687-9	TORSION SPRING 17 / JR3070CT	1	
016	213151-2	OIL SEAL 14 /6901D	1	
017	213174-0	X RING 14 /JR3030T	1	
018	154813-2	"GEAR HOUSING COVER COMPLETE INC.16,17." INC. 16,17	1	
019	418806-6	CAP /JR3050T	1	
020	631689-9	LED CIRCUIT /BJR181RF	1	
021	911243-8	PAN HEAD SCREW M5 X 25 /9901/BPB180Z	4	
022	232221-8	LEAF SPRING A /JR3050T	1	
023	162236-0	SHIFT BUTTON /JR3050T	1	
024	421946-1	SEAL RING /BJR181RF	1	
025	345480-6	SLIDE PLATE /JR3050T	1	
026	214170-1	PLANE BEARING 14A / JR3070CT	1	
027	341462-6	PLATE /JR3000/BJR240SJE	1	
028	911225-0	P.H.SCREW M5 X 16 /JR3030T/BJR240SJE	2	
029	154788-5	SLIDER COMPLETE /BJR181RF/JR3050T	1	
030	214170-1	PLANE BEARING 14A / JR3070CT	1	
031	341462-6	PLATE /JR3000/BJR240SJE	1	
032	911225-0	P.H.SCREW M5 X 16 /JR3030T/BJR240SJE	2	
033	265148-7	TORX SOCKET HEAD SCREW M5X14 /JR3050T	2	
034	344795-8	PLATE C /JR180DWA	1	
035	265148-7	TORX SOCKET HEAD SCREW M5X14 /JR3050T	2	
036	344795-8	PLATE C /JR180DWA	1	
037	*****	*****	***	*****
038	*****	*****	***	*****
039	*****	*****	***	*****
040	253797-2	FLAT WASHER 14 /HR2220	1	
041	232222-6	LEAF SPRING B /JR3050T	1	
042	345479-1	SHOE GUIDE /JR3050T	1	
043	265165-7	TORX SOCKET C.S. HEAD SCREW / JR3050 /	1	
044	266041-8	TAPPING SCREW FLANGE PT 5X25/KP0810	4	
045	154812-4	GEAR HOUSING COMPLETE /BJR181RF	1	
046	912207-5	COUNTERSUNK HEAD SCREW M5x10/BJR181RF	2	
047	951057-3	SPRING PIN 3-12 /4334DWA	1	
048	313127-0	JOINT /BJR181RF	1	
049	233455-6	COMPRESSION SPRING 7	1	
050	262561-0	SLEEVE 6	1	
051	281218-4	HOOK	1	
052	264002-2	SQUARE NUT / KP0810	2	
053	125321-0	HOOK ASS'Y INC.47-51/BJR181RF INC. 47-51	1	
054	961052-5	RETAINING RING S-12/9556PB/BSS610/MT940	1	

SPARE PARTS LIST

MODEL NO. BJR181

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
055	210102-6	BALL BEARING 6001DDW /JR3050T	1	
056	961016-9	STOP RING E-10 /2703/BJR240SJE	1	
057	911225-0	P.H.SCREW M5 X 16 /JR3030T/BJR240SJE	2	
058	285726-7	BEARING RETAINER 63/BJR181RF	1	
059	241869-5	FAN 55 /JR180DWA/5621DWFE/BSS610/HP1630K	1	
060	519176-7	ARMATURE ASS'Y 18VOLT/ BJR181RF INC. 59,61	1	
061	210062-2	BALL BEARING /MT951/MT953/MT600/MT601	1	
062	419333-6	BAFFLE PLATE /BJR181RF	1	
063	638107-8	YOKE UNIT /BJR240SJE/BSS610	1	
064	419327-1	COVER /BJR181RF	1	
065	419330-2	MOTOR HOUSING /BJR181RF	1	
066	266292-3	TAPPING SCREW 4 X 65 /BJR240SJE/BSS610	2	
067	643941-3	HOLDER CAP /5620DWA/5621DWFE/LS800DWA	2	
068	*****	*****	***	*****
069	643949-7	BRUSH HOLDER R /JR180DWA/BJR240SJE	1	
070	*****	*****	***	*****
071	188046-7	HANDLE SET INC.82 /BJR181RF INC. 82	1	
072	*****	*****	***	*****
073	419336-0	SWITCH LEVER /BJR181RF	1	
074	650574-7	SWITCH C3LA-2A-LLM /BJR181RF	1	
075	232152-1	LEAF SPRING /6832	1	
076	419334-4	LOCK OFF BUTTON /BJR181RF	1	
077	631690-4	POWER SUPPLY CIRCUIT /BJR181RF	1	
078	643815-8	BRUSH HOLDER /BJR181RF	1	
079	911006-2	P.H. SCREW M3 X 8 /BHR200SFE/BHR200SJE	1	
080	689116-0	HEAT SINK /BJR240SJE	1	
081	266045-0	TAPPING SCREW FL.PT 4x20/BHP441/BHP444RF	6	
082	188046-7	HANDLE SET INC.82 /BJR181RF INC. 71	1	
A01	*****	*****	***	*****
A02	*****	*****	***	*****
A04	824760-8	PLASTIC CARRYING CASE	1	
A05	B-05169	RECIPRO SAW BLADE	1	
A06	B-05175	RECIPRO SAW BLADE	1	

SERVICE DRAWING

MODEL NO. BJR181

