

# SPARE PARTS LIST

MODEL NO. BHS630

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	141237-1	HANDLE COVER COMPLETE	1	
002	643859-8	TERMINAL	1	
003	419664-3	LOCK OFF LEVER	1	
004	650631-1	SWITCH	1	
005	231469-9	COMPRESSION SPRING 4	1	
006	419665-1	SWITCH LEVER	1	
007	620054-7	CONTROLLER	1	
008	231469-9	COMPRESSION SPRING 4	1	
009	140984-1	MOTOR HOUSING COMPLETE	1	
010	265995-6	TAPPING SCREW 4X18	7	
011	896399-7	BHS630 NAME PLATE	1	
012	643813-2	BRUSH HOLDER	1	
013	265995-6	TAPPING SCREW 4X18	2	
014	452787-4	REAR COVER	1	
015	643941-3	BRUSH HOLDER CAP	2	
016	194435-6	CARBON BRUSH CB-441	1	
017	643814-0	BRUSH HOLDER	1	
018	911258-5	PAN HEAD SCREW M5X35	3	
019	266026-4	TAPPING SCREW BIND CT 4X12	1	
020	452790-5	DUCT	1	
021	452789-0	BLADE COVER	1	
022	266292-3	TAPPING SCREW 4X65	2	
023	638571-3	YOKE UNIT	1	
024	452785-8	BAFFLE PLATE	1	
025	266026-4	TAPPING SCREW BIND CT 4X12	1	
026	331947-0	PIPE 6	1	
027	266020-6	TAPPING SCREW 4X12	1	
028	272270-3	LEVER 39	1	
029	210023-2	BALL BEARING 627DDW	1	
030	519288-6	ARMATURE ASSEMBLY 18V	1	
		INC. 29,31,32		
031	241869-5	FAN 55	1	
032	210051-7	BALL BEARING 609LLB	1	
033	344681-3	SHAFT LOCK	1	
034	233117-6	COMPRESSION SPRING 6	1	
035	266458-5	HEX.SOCKET HEX.BOLT M6X18	1	
036	224421-4	OUTER FLANGE 28	1	
037	224417-5	INNER FLANGE 28	1	
038	257938-2	RETAINING RING(EXT) WR-26	1	
039	267127-1	FLAT WASHER 26	1	
040	452791-3	SAFETY COVER	1	
041	231874-0	TENSION SPRING 4	1	
042	345470-9	THICKNESS RING	1	
043	324859-4	SPINDLE	1	
044	911128-8	PAN HEAD SCREW M4X16	4	
045	140983-3	BEARING BOX COMPLETE	1	
046	442141-0	GASKET	1	
047	210069-8	BALL BEARING 6900DDW	1	
048	285847-5	BEARING RETAINER 14-23	1	
049	257284-3	RING 10	1	
050	227718-0	HELICAL GEAR 24	1	
051	961006-2	RETAINING RING S-10	1	
052	262155-1	RUBBER RING 10	1	
053	267369-7	FLAT WASHER 11	1	
054	211012-0	BALL BEARING 606ZZ	1	
055	227717-2	HELICAL GEAR 17	1	

# SPARE PARTS LIST

MODEL NO. BHS630

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
056	226676-7	HELICAL GEAR 39	1	
057	253823-7	FLAT WASHER 7	1	
058	264064-0	HEX.NUT M6	1	
059	266229-0	H.S.SET SCREW(CUP POINT)M5X8	1	
060	141002-8	BLADE CASE COMPLETE	1	
061	262511-5	RUBBER SLEEVE 6	1	
062	265115-2	+ PAN HEAD SCREW M5	1	
063	452786-6	CONNECTOR BOX	1	
064	452788-2	COVER	1	
065	266042-6	TAPPING SCREW BIND CT 4X20	1	
066	631694-6	LED CIRCUIT	1	
067	961014-3	STOP RING E-8	1	
068	272260-6	LEVER 55	1	
069	265595-2	HEX.BOLT M6X85	1	
070	253804-1	FLAT WASHER 6	1	
071	346477-8	COLLOR	1	
072	318245-9	DEPTH GUIDE	1	
073	346477-8	COLLOR	1	
074	922137-2	HEX. SOCKET HEAD BOLT M4X20	1	
075	345876-1	REAR ANGULAR GUIDE	1	
076	252126-6	HEX. LOCKING NUT M4-7	1	
077	256480-0	SHOULDER PIN 6-7	1	
078	961012-7	STOP RING E-6	2	
079	453165-1	LOCK LEVER	2	
080	265571-6	HEX. BOLT M6X10	2	
081	233596-8	TORSION SPRING 11	2	
082	256480-0	SHOULDER PIN 6-7	1	
083	265072-4	+ PAN HEAD SCREW M5	1	
084	345590-9	ANGULAR GUIDE	1	
087	252103-8	HEX. LOCK NUT M5-8	1	
096	265708-5	SCREW M6X20	1	
097	942151-2	SPRING WASHER 6	1	
098	941151-9	FLAT WASHER 6	1	
099	266039-5	H.S.SET SCREW(FLAT POINT) M6X6	1	
100	310511-0	BASE	1	
101	266039-5	H.S.SET SCREW(FLAT POINT) M6X6	1	
103	266208-8	H.S.SET SCREW(CUP POINT)M6X8	1	
104	911109-2	PAN HEAD SCREW M4X8	1	
105	450333-7	TOP GUIDE	1	
106	265708-5	SCREW M6X20	1	
107	942151-2	SPRING WASHER 6	1	
108	941151-9	FLAT WASHER 6	1	
A01	164095-8	GUIDE RULE	1	
A02	783203-8	HEX. WRENCH 5	1	
A03	D-26630	T.C.T.SAW BLADE 165X20X16T	1	
A05	***DC18RC	DC18RC FAST CHARGER	1	
A06	194204-5	BATTERY BL1830 SET	2	
A07	824995-1	PLASTIC CARRYING CASE	1	
A08	890284-6	BHS630RFE PLASTIC CASE LABEL	2	
A09	450128-8	BATTERY COVER	1	

# SERVICE DRAWING

MODEL NO. BHS630

