

SPARE PARTS LIST

MODEL NO. LC1230

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	151625-4	MOTOR HOUSING COMPLETE /LC1230	1	
002	851537-8	NAME PLATE LC1230	1	
003	266028-0	TAPPING SCREW 5x40 /4130/LC1230	4	
004	253749-3	FLAT WASHER 16 /2106/LC1230/BPB180Z	1	
005	*****	*****	***	*****
006	681633-6	INSULATION WASHER /LS1211/LC1230	1	
007	636169-0	FIELD /LC1230	1	
008	266059-9	SELF TAP SCREW 5x75 /9057/LC1230/2414B	2	
009	415475-4	BAFFLE PLATE /LC1230	1	
010	516574-6	ARMATURE /LC1230	1	
		INC. 5,6		
011	267714-6	WASHER 15 /2414B/LC1230	1	
012	211206-7	BALL BEARING 6202LLB /BJR240SJE/LS1040	1	
013	316626-1	GEAR HOUSING LEFT /LC1230	1	
014	226122-0	GEAR COMPLETE 16-44 /LC1230	1	
015	211064-1	BALL BEARING 6000 /LC1230/BTL061Z	1	
016	231418-6	COMPRESSION SPRING 9 /9803/LC1230	1	
017	322678-2	SHAFT LOCK /LC1230	1	
018	961014-3	STOP RING E-8 /3901/5620DWA/5621DWFE	1	
019	191953-5	CARBON BRUSH CB-203	1	
020	643700-5	BRUSH HOLDER CAP 7-18 /GA9020 /GA9030	2	
021	266032-9	TAPPING SCREW BIND CT 5x30 /LC1230	1	
022	265995-6	TAPPING SCREW4x18/HR2440F/HR2450F/BSS610	4	
023	182628-7	HANDLE SET /2414B/LC1230	1	
		INC. 33		
024	411478-6	LOCK-OFF SWITCH BUTTON (REMOVABLE)	1	
025	266033-7	TAPPING SCREW BIND 5x50 /LC1230	2	
026	281207-9	HANGER /2416S/LC1230	1	
027	256012-3	PIN 6 /6801B/LC1230	1	
028	*****	*****	***	*****
029	231397-8	COMPRESSION SPRING 4 /2414B/LC1230	1	
030	651922-3	SWITCH TG71B /HM1304/KP0810 /HR4002	1	
031	415366-9	SWITCH LOCK /2414B/LC1230	1	
032	152463-7	SWITCH LEVER COMPLETE /2414NB/LC1230	1	
033	182628-7	HANDLE SET /2414B/LC1230	1	
		INC. 23		
034	265995-6	TAPPING SCREW4x18/HR2440F/HR2450F/BSS610	2	
035	687053-2	STRAIN RELIEF/LS1214B/HR2450/HP2051/9032	1	
036	682505-8	CORD GUARD /LS1013B/LS1214B/LS1040	1	
037	666448-2	POWER SUPPLY CORD 1.0-2-2.3	1	
038	211064-1	BALL BEARING 6000 /LC1230/BTL061Z	1	
039	226427-8	HELICAL GEAR 38 /LC1230	1	
040	211061-7	BALL BEARING 6000LLB /LS1214B/LS1013B	1	
041	317148-4	GEAR HOUSING RIGHT /LC1230	1	
042	266034-5	TAPPING SCREW CT 4 X 16 /HK0500/LS1013B/	2	
043	416869-6	PROTECTOR /LC1230	1	
044	231226-5	COMPRESSION SPRING 11 /2040/LC1230	1	
045	415474-6	BLADE GUIDE /LC1230	1	
046	266030-3	SCREW M6 /LC1230	1	
047	257139-2	RING 20 /LC1230	1	
048	211329-1	BALL BEARING 6204DDW /LC1230	1	
049	254229-2	KEY 5 /HR4000C/HR5001C/LC1230/HR5201C	1	
050	323828-2	SPINDLE /LC1230	1	
051	224308-0	INNER FLANGE 70 /LC1230	1	
052	*****	*****	***	*****
053	265414-2	HEX FLANGE HEAD BOLT M10x20 /LC1230	1	

SPARE PARTS LIST

MODEL NO. LC1230

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
054	183089-4	BLADE CASE SET /LC1230 INC. 56	1	
055	256405-4	PIN 6-7 /LC1230	2	
056	819064-1	MAKITA MARK /5901B/5902B/LS1013B/LS1214B	1	
057	344737-2	CENTER COVER /LC1230	1	
058	266035-3	TAPPING SCREW CT 5X12 /2703/9031/LC1230	2	
059	911383-2	PAN HEAD SCREW M6X60 /2703/LC1230	4	
060	265414-2	HEX FLANGE HEAD BOLT M10x20 /LC1230	1	
061	*****	*****	***	*****
062	266034-5	TAPPING SCREW CT 4 X 16 /HK0500/LS1013B/	2	
063	344735-6	CETER SUPPORT /LC1230	1	
064	344734-8	CENTER WASHER /LC1230	1	
065	344736-4	CENTER PLATE /LC1230	1	
066	922107-1	H.S.H. M4 X 8 /4322/4323/LC1230/AF502	2	
067	231643-9	TORSION SPRING 38 /LC1230	1	
068	317152-3	SAFETY COVER /LC1230	1	
069	256098-7	PIN 5 /LC1230/LS800DWA	1	
070	323882-6	COLLARED SHAFT 12 /LC1230	1	
071	253843-1	FLAT WASHER 12 /LC1230/HR5201C	1	
072	911103-4	PAN HEAD SCREW M4 X 6	1	
073	816128-2	POINTER /5903/LC1230/LS1013B/LS1214B	1	
074	310086-9	WISE /LC1230	1	
075	256453-3	PIN 12 /LC1230	1	
076	233103-7	COMPRESION SPRING 45 /LC1230	1	
077	165066-8	SPRING HOLDER /2414B/LC1230	1	
078	265412-6	HEX.BOLT M8 X 20 /LC1230/LS1013B/LS1214B	1	
079	266034-5	TAPPING SCREW CT 4 X 16 /HK0500/LS1013B/	1	
080	232075-3	LEAF SPRING WRENCH HOL /LS1211/LC1230	1	
081	265413-4	HEX BOLT M16 /LC1230	1	
082	253771-0	FLAT WASHER 16 /2400B/LC1230	1	
083	252044-8	HEX LOCK NUT M16-24 /2400B/LC1230	1	
084	344740-3	DUST BOX /LC1230	1	
085	421671-4	RUBBER PAD /LC1230	1	
086	421670-6	CUSHION /LC1230	1	
087	257222-5	RING 8 /LC1230	1	
088	253731-2	FLAT WASHER 8 /6300-4/LC1230/4107RH	2	
089	268040-6	PIN 16 /LC1230	1	
090	344118-0	VICE PLATE /LC1230	1	
091	344738-0	LINK PLATE /LC1230	1	
092	*****	*****	***	*****
093	*****	*****	***	*****
094	912212-2	C.S.H. SCREW M5 X 12 /LC1230	3	
095	344119-8	GUIDE PLATE /LC1230	1	
096	344739-8	UNDER PLATE /LC1230	1	
097	266026-4	TAPPING SCREW BIND M4x12 /9032/LS1214B/	3	
098	286212-1	CAP 20 /LS1011/LC1230/LS800DWA/LS1013B	5	
099	151623-8	BASE COMPLETE /LC1230	1	
100	286236-7	CAP 16 /LS1211/LC1230	1	
101	961014-3	STOP RING E-8 /3901/5620DWA/5621DWFE	2	
102	323883-4	LEVER ROD 10 /LC1230	1	
103	253024-7	FLAT WASHER 10 /LS1214B/LS1013B	1	
104	252161-4	HEX NUT M10-17 /LC1230	1	
105	151622-0	LEVER HOLDER COMPLETE /LC1230	1	
106	941152-7	FLAT WASHER 6 /HM1800/HR5001C/LC1230	1	
107	265381-1	HEX.BOLT M6 X 16 /LS0711B/LS800DWA	1	
108	951063-8	SPRING PIN 3-16 /LC1230/AN943	1	


SPARE PARTS LIST

MODEL NO. LC1230

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
109	322679-0	VICE SCREW /LC1230	1	
110	322209-7	WISE NUT /LS1510/LC1230	1	
111	911451-1	P.H. SCREW M8 X 30 /LC1230	2	
112	311949-2	SCREW GUIDE /2414/LC1230/2416S	1	
113	*****	*****	***	*****
114	951166-8	SPRING PIN 5-24 /LC1230/HR5201C/HR5211C	1	
115	257157-0	RING 8 /LS0810/LC1230	1	
A01	782210-8	SOCKET WRENCH 17MM /2414NB/LC1230/2416S	1	
A02	192219-6	SAFETY GOGGLE	1	
A03	A-87242	TCT SAW BLADE 305X25.4X60T /LC1230	1	
A04	411478-6	LOCK-OFF SWITCH BUTTON (REMOVABLE)	2	
E01	645200-1	NOISE SUPPRESSOR /9077S/9526B/9528B/2703	1	

SERVICE DRAWING

MODEL NO. LC1230



SERVICE DRAWING

MODEL NO. LC1230

